

Casing position

Direction of rotation (seen via drive)

	LEFT - LG left (counterclockwise)	RIGHT - RG right (clockwise)
360	LG 360	RG 360
045	LG 045	RG 045
090	LG 090	RG 090
135	LG 135	RG 135
270	LG 270	RG 270
315	LG 315	RG 315
180	LG 180-TR LG 180-AT	RG 180-AT RG 180-TR